











# 28 Alva 3x3

ID	Name	Height	Width	Length	Qty	3D Front Axonometry	
FBE-1	Floor bearer	28	60	2800	6		—
A01	Wall A	135	28	1297	7		⌋
A02	Wall A	135	28	293	14		⌋
A03	Wall A	135	28	293	7		⌋
A04	Wall A	135	28	294	7		⌋
B01	Wall B	135	28	3000	14		⌋
C01	Wall C	135	28	3000	1		⌋
C02	Wall C	135	28	3000	6		⌋
C03	Wall C	135	28	845	5		⌋
C04	Wall C	135	28	845	7		⌋
C05	Wall C	135	28	1245	1		⌋
C06	Wall C	135	28	1745	1		⌋
C07	Wall C	135	28	4400	1		⌋
D01	Wall D	135	28	3000	1		⌋
D02	Wall D	135	28	3000	11		⌋
D03	Wall D	135	28	3400	1		⌋
D04	Wall D	135	28	3900	1		⌋
D05	Wall D	135	28	4400	1		⌋
Extra01	Wall Extra	135	28	4400	1		⌋
GBL01	Gable ends	135	28	3000	2		⌋
GBL02	Gable ends	135	28	2349	2		⌋
GBL03	Gable ends	135	28	1566	2		⌋
GBL04	Gable ends	135	28	783	2		⌋
PR-1	Purlin	140	44	4400	2		⌋
PR-2	Purlin	140	44	4400	1		⌋
RB-1	Roof board	19	87/110/135	1745	103/82/67		—
FB-1	Floor board	19	87/110/135	2739	33/26/21		—
TRIM	Trim	40	19		12 m'		
WBA	Windboard A	90	19	1864	4		⌋
WBB	Windboard B	70	19	4400	2		⌋

Gaminamos detalės  
297mm reikia pripjauti

Alva 3x3 28mm Packing list

WBC	Windboard C	19	40	1864	4		-
WBD	Windboard D	25	30	4400	2		□
WB-RMB	Rhombus	200	19	19	2		◇
STRM-BR	Storm braces	47	28	1980	4		□
<b>Instalaltion kit for assembly</b>							
N01	Nail	---	2,5	40	550 (500+50)		●
S-01	Screw	---	3	40	100		⊕
S-03	Screw	---	5	100	10		⊕
S-04	Screw	---	5	120	10		⊕
SB	Washer	---	M10	---	8		○
	Screw	---	8	50	8		⊕