






























28 Emma 3x3

ID	Name	Height	Width	Length	Qty	3D Front Axonometry	
FBE-1	Floor bearer	28	60	2800	6		-
A01	Wall A	135	28	297	14		
A02	Wall A	135	28	297	14		
B01	Wall B	135	28	3000	14		
C01	Wall C	135	28	3000	1		
C02	Wall C	135	28	3000	6		
C03	Wall C	135	28	845	6		
C04	Wall C	135	28	845	7		
C05	Wall C	135	28	995	1		
C06	Wall C	135	28	3400	1		
D01	Wall D	135	28	3000	1		
D02	Wall D	135	28	3000	12		
D03	Wall D	135	28	3150	1		
D04	Wall D	135	28	3400	1		
Extra01	Wall Extra	135	28	3400	1		
GBL01	Gable ends	135	28	3000	2		
GBL02	Gable ends	135	28	2349	2		
GBL03	Gable ends	135	28	1564	2		
GBL04	Gable ends	135	28	779	2		
PR-1	Purlin	140	44	3400	2		

Emma 3x3 28mm Packing list

PR-2	Purlin	140	44	3400	1		
RB-1	Roof board	19	87/110/135	1745	79/63/51		
FB-1	Floor board	19	87/110/135	2739	33/26/21		
TRIM	Trim	40	19		13 m'		
WBA	Windboard A	90	19	1864	4		
WBB	Windboard B	70	19	3400	2		
WBC	Windboard C	19	40	1864	4		
WBD	Windboard D	25	30	3400	2		
WB-RMB	Rhombus	200	19	19	2		
STRM-BR	Storm braces	47	28	1980	4		
Installation kit for assembly							
N01	Nail	---	2,5	40	450 (200*2+50)		
S-01	Screw	---	3	40	100		
S-03	Screw	---	5	100	10		
S-04	Screw	---	5	120	10		
SB	Washer	---	M10	---	8		
	Screw	---	8	50	8	