















28 Imperial 3x3

ID	Name	Height	Width	Length	Qty	3D Front Axonometry	
FBE-1	Floor bearer	28	60	2800	6		-
A01	Wall A	135	28	795	14		
A02	Wall A	135	28	795	14		
B01	Wall B	135	28	3000	14		
C01	Wall C	68	28	3000	1		
C02	Wall C	135	28	3000	10		
C03	Wall C	135	28	3200	1		
C04	Wall C	135	28	3500	1		
C05	Wall C	135	28	3800	1		
C06	Wall C	135	28	4200	1		
D01	Wall D	68	28	3000	1		
D02	Wall D	135	28	3000	6		
D03	Wall D	135	28	1145	4		
D04	Wall D	135	28	1145	7		
D05	Wall D	135	28	1345	1		
D06	Wall D	135	28	1645	1		
D07	Wall D	135	28	1945	1		
D08	Wall D	135	28	4200	1		
Extra01	Wall Extra	135	28	4200	1		
GBL01	Gable ends	135	28	3000	2		
GBL02	Gable ends	135	28	2354	2		
GBL03	Gable ends	135	28	1570	2		
GBL04	Gable ends	135	28	785	2		
PR-1	Purlin	140	44	4200	2		
PR-2	Purlin	140	44	4200	1		
RB-1	Roof board	19	87/110/135	1745	99/78/64		-
FB-1	Floor board	19	87/110/135	2739	33/26/21		-
TRIM	Trim	40	19		13 m'		
WBA	Windboard A	90	19	1864	4		
WBB	Windboard B	70	19	4200	2		
WBC	Windboard C	19	40	1864	4		-
WBD	Windboard D	25	30	4200	2		

Imperial 3x3 28mm Packing list

WB-RMB	Rhombus	200	19	19	2		
STRM-BR	Storm braces	47	28	1980	4		
Installation kit for assembly							
N01	Nail	---	2,5	40	550 (500+50)		
S-01	Screw	---	3	40	100		
S-03	Screw	---	5	100	10		
S-04	Screw	---	5	120	10		
SB	Washer	---	M10	---	8		
	Screw	---	8	50	8	