

















































































## 28 Modena 3x2,5

ID	Name	Height	Width	Length	Qty	3D Front Axonometry	
FBE-1	Floor bearer	28	60	2800	5		-
A01	Wall A	135	28	476	14		
A02	Wall A	135	28	1664	7		
A03	Wall A	135	28	478	7		
A04	Wall A	135	28	476	7		
B01	Wall B	135	28	3000	14		
C01	Wall C	135	28	2500	1		
C02	Wall C	135	28	2500	10		
C03	Wall C	135	28	2700	1		
C04	Wall C	135	28	3000	1		
C05	Wall C	135	28	3300	1		
C06	Wall C	135	28	3700	1		
D01	Wall D	135	28	2500	1		
D02	Wall D	135	28	2500	6		
D03	Wall D	135	28	895	4		
D04	Wall D	135	28	895	7		
D05	Wall D	135	28	1095	1		
D06	Wall D	135	28	1395	1		
D07	Wall D	135	28	1695	1		
D08	Wall D	135	28	3700	1		
Extra01	Wall Extra	135	28	3700	1		
GBL01	Gable ends	135	28	3000	2		
GBL02	Gable ends	135	28	2354	2		
GBL03	Gable ends	135	28	1570	2		
GBL04	Gable ends	135	28	785	2		

Modena 3x2,5 28mm Packing list

PR-1	Purlin	140	44	3700	2		
PR-2	Purlin	140	44	3700	1		
RB-1	Roof board	19	87/110/135	1745	87/69/56		
FB-1	Floor board	19	87/110/135	2239	33/26/21		
TRIM	Trim	40	19		12 m'		
WBA	Windboard A	90	19	1864	4		
WBB	Windboard B	70	19	3700	2		
WBC	Windboard C	19	40	1864	4		
WBD	Windboard D	25	30	3700	2		
WB-RMB	Rhombus	200	19	19	2		
STRM-BR	Storm braces	47	28	1980	4		
<b>Installation kit for assembly</b>							
N01	Nail	---	2,5	40	450 (200+200+50)		
S-01	Screw	---	3	40	100		
S-03	Screw	---	5	100	5		
S-04	Screw	---	5	120	10		
SB	Washer	---	M10	---	8		
	Screw	---	8	50	8	