










28 Suzie 3,5x2,5							
ID	Layer	Height	Width	Length	Qty	3D Front Axonometry	
FBE-1	Floor bearer	44	60	2300	2		
FBE-2	Floor bearer	44	60	3180	5		
A01	Log wall	68	28	450	1		
A02	Log wall	68	28	1640	1		
A03	Log wall	135	28	450	13		
A04	Log wall	135	28	1640	4		
A05	Log wall	135	28	1640	1		
A06	Log wall	135	28	480	8		
A07	Log wall	135	28	450	8		
A08	Log wall	135	28	3500	1		
A09	Log wall	135	28	3500	1		
A10	Log wall	135	28	3700	1		
A11	Log wall	68	28	3700	1		
B01	Log wall	68	28	3500	1		
B02	Log wall	135	28	3500	14		
B03	Log wall	135	28	3700	1		
C01	Log wall	135	28	2500	5		
C02	Log wall	135	28	450	8		
C03	Log wall	135	28	1340	8		

C04	Log wall	135	28	850	1		
C05	Log wall	135	28	1340	1		
C06	Log GBL	135	28	3300	1		
C07	Log GBL	135	28	3300	1		
C08	Log GBL	135	28	2439	1		
C09	Log GBL	135	28	1219	1		
D01	Log wall	135	28	2500	13		
D02	Log wall	135	28	2900	1		
D03	Log GBL	135	28	3300	1		
D04	Log GBL	135	28	3300	1		
D05	Log GBL	135	28	2439	1		
D06	Log GBL	135	28	1219	1		
Extra01	Log wall	135	28	3500	1		
PR-1	Purlin	140	44	3700	1		
PR-2	Purlin	140	44	3700	2		
RB	Roof board	19	135/110/87	1844	56/68/87		
FB	Floor board	19	135/110/87	2239	25/31/38		
TRIM	Trim	22	28		12 m		
STRM-BR	Storm braces	47	28	1980	4		
WBA	Windboard	113	19	1905	4		
WBB	Windboard	70	19	3700	2		

WBC	Windboard	19	40	1905	4		-
WBD	Windboard	25	30	3700	2		▣
RMB	Rhombus	200	19	19	2		◆
Installation kit for assembly							
N01	Nail	---	2,5	40	500		●
S-01	Screw	---	3	40	100		⊕
S-03	Screw	---	5	100	10		⊕
S-04	Screw	---	5	120	20		⊕
SB	Washer	---	M10	---	8		⊙
	Screw	---	8	50	8		⊕